



Portable hand-crank 8x10 Processor QUICKSTART



1. Open the processor



2. Insert the positive sheet with pods ahead under the metal, pushing as far as it will go toward rollers



3. Now insert the loaded cassette into the processor, pushing as far as it will go toward rollers



4. Turn crank clockwise about 4 revolutions



5. Remove the film

Questions?

Write to service@supersense.com